








HERMAN TV STAND

ASSEMBLY MANUEL



*In order to provide better service to you again and gain to the production process of the use of non-recycled waste material support, please let us ... Let us preserve the environment for a better WORLD....
Thank you for choosing us :)*



**Dear Customer,**

We are delighted to meet your needs and hope you enjoy our products. May they bring joy to you and your family. Please be assured that this product has successfully passed all safety and health tests.

Thank you for choosing us!


**Assembly Recommendations**

We kindly recommend checking the components and accessories listed in the installation guide before beginning assembly.

If you have purchased multiple products (we're happy to hear that!), we suggest completing the assembly of the first product before moving on to the second.



We recommend that you clean all parts with a slightly damp cloth before assembling the product.

**Safety Instructions**


Please avoid using the products for purposes other than their intended use. It is crucial for the safety and well-being of you and your family to prevent any risk of injury.

To ensure the longevity of the product, please keep it away from excessive heat, cold, and humidity.

**WARNING!**

Securing the furniture to the wall is highly recommended for your safety. Furniture tip-overs can result in serious injuries or even fatal accidents. To prevent such risks, please ensure your furniture is securely fixed to the wall.

Please note that fixing devices are not included in the package, as different wall types require different solutions. Use suitable fixing devices that you trust. If you are unsure which devices to use, we recommend consulting your local dealer for guidance.








The necessary tools (not included)


ACCESSORY LIST

A22 28x	A23 28x	A04 12x	A06 18 mm TP A-28x	A45 MSM.00019 SYH 1x
A46 MSM.00019 SYH 2x	A11 4 SW 1x	A21 LA 50*20 1x	A48 AC 35x	C04 D MA 4x
C01 DM 4x	A16 DB 8mm 1x	A18 YHB VD 3,5x18 17x	A41 YHB VD 4x30 13x	A42 YHB VD 5x70 1x
B15 6*25mm 6x				


GENERAL VIEW










4






5






A= menteşe bağlama vidası / to connect the hinge to the door
B= kapak ayar vidası / to arrange the door




oklar kapağın ayarlama yönünü gösterir.
arrows to show the directions for arrangement of doors.


7




8




9




10




PART-1




PART-2





PART-3




PART-4



PART-5





Have you seen our other products ?