



ATTACH WOODEN LEGS TO THE SOFA BY SPINNING WITH YOUR HANDS

